

Dry Fit Instructions

Tools

- 1) Dry Fit Templates (enclosed)
- 2) Scissors
- 3) Permanent Marker
- 4) Worksheet (enclosed)

Instructions

- 1) Use scissors to cut out each templated part leaving as much clear vinyl film as possible around each part in case you need to make a size increase.
- 2) Place each part on your boat in the exact position in which it will be applied. If there is a molded in pattern on your boat, the parts should be aligned to the pattern, or extend ¼" past to a smooth surface.
- 3) Verify that each piece fits.
- 4) If your pads will have a pattern such as teak lines, please verify the pattern alignment from part to part.
- 5) If a change is needed, notate the change clearly with your marker.
- 6) If you need more room to trace your part, please attach additional vinyl film to the edge, taping it to the underside.
- 7) Revisions should be made as clearly as possible so that the additional revisions will not be required.
- 8) When all revisions are complete, please fill out the form below and mail the clear vinyl film and paperwork back to SeaDek Marine Products.
- 9) Once your package is received and scanned into our system you will receive an email confirmation with your expected lead time.
 - o If you do not have an active order, you will be emailed a quote for your project. Your project will not start until you call in to place your deposit.
- 10) If no changes are required, there is no need to send the Dry Fits back. Sending the Dry Fits could cause confusion and may delay processing time.
- 11) If the Dry Fits are correct "as is", simply reply to your original drawing approval email, and await instructions from your sales representative.

