



DRY FIT INSTRUCTIONS

TOOLS

- 1) Dry Fit Templates (enclosed)
- 2) Scissors
- 3) Permanent Marker
- 4) Worksheet (enclosed)

INSTRUCTIONS

- 1) Use scissors to cut out each templated part leaving as much clear vinyl film as possible around each part in case you need to make a size increase.
- 2) Place each part on your boat in the exact position in which it will be applied. If there is a molded in pattern on your boat, the parts should be aligned to the pattern, or extend $\frac{1}{4}$ " past to a smooth surface.
- 3) Verify that each piece fits.
- 4) If your pads will have a pattern such as teak lines, please verify the pattern alignment from part to part. Align the parts with the appropriate space as shown on the drawing prior to making adjustments. When making adjustments do not adjust the split. Due to natural expansion/contraction of foam, we allow $\frac{1}{2}$ " gap between pads.
- 5) If a change is needed, notate the change clearly with your marker.
- 6) If you need more room to trace your part, please attach additional vinyl film to the edge, taping it to the underside.
- 7) Revisions should be made as clearly as possible so that the additional revisions will not be required.
- 8) Take photos of the Dry Fit on the surface and email them to endusersales@seadek.com

When all revisions are complete, please fill out the form on the next page and mail the clear vinyl film and paperwork back to the address below.

**SEADEK MARINE PRODUCTS
5440 SCHENCK AVE
ROCKLEDGE, FL 32955**



