



How to Clean SeaDek

To assist with removing dirt, footprints, suntan lotion, fish blood, rust, and other hard to clean residues from your SeaDek, use our Dek Magic cleaner.

Spray Dek Magic liberally to cover the area needing to be cleaned. With a medium bristled boat brush, lightly work the product in. Let the cleaner sit for 3-5 minutes. Use water to dampen the affected area and lightly scrub the area for a second time. Rinse the cleaner off thoroughly and dry with a clean towel. If you encounter a stubborn stain, repeat these steps as needed.

If Dek Magic is not available, see the below steps for other cleaning options.

- 1) To clean dirt, footprints, etc. from your SeaDek, use an all-purpose cleaner, degreaser, or dish soap along with warm water and a medium bristled brush. Put the cleaner or soap in warm water. Take a medium bristled brush and dunk into the water mixture. Work around on SeaDek until dirt, etc. comes up. Rinse with clean water. Repeat if necessary.
- 2) To remove suntan lotion, use the all-purpose cleaner or degreaser alone with a medium bristled brush. Put small amount of the cleaner on the oil stain. Dip medium bristled boat brush in warm water and work around until oil is out. Rinse with clean water. Repeat if needed.
- 3) To remove fish blood, use 1 cup bleach to 1 gallon of warm water and soft bristled brush. Mix bleach and water. Take a soft bristled brush and dunk in the mixture. In a circular motion clean SeaDek until fish blood is up. Rinse thoroughly with clean water. Repeat if necessary. If not effective, see step 4.
- 4) To remove rust stains, use a cap full of vinegar or oxalic acid. Apply on the rust stain and allow to soak for 3-5 minutes. If necessary, use latex/nitrile gloves to massage the cleaner into the texture of the SeaDek pad. Rinse with water. Repeat if necessary. With oxalic acid, please be careful to avoid getting this solvent on the sides of the SeaDek pad, it could damage the lamination or PSA.

Please follow your state and/or country regulations for proper chemical handling.

Please be careful with all cleaning products. Wear vinyl or nitrile gloves and eye protection.

Use With Care

- Acetone (if it must be used, avoid the adhesives as best as possible)
- Bleach (if used, dilute 1 cup with 1 gallon of water)

For best cleaning results, tend to all stains, spills and leaks as soon as possible.